

### Using Atlas 14 Data with NRCS/SCS Methodology for MnDOT projects

Dec, 2015

We all have a stake in  $A \oplus B$ 



















## Atlas 14 data with NRCS Methodology

- NRCS Hydrology methodology review
- Minnesota NRCS recommendation
- MnDOT recommendation
- Using Atlas 14 with HydroCAD



















#### NRCS Hydrology

- NRCS Natural Resource Conservation Service (formerly known as SCS - Soil Conservation Service) developed/support rainfall/runoff hydrology method
- NRCS uses to design small agricultural ponds, waterways and erosion control
- NRCS Hydrology methods typically used by MnDOT and most others in Minnesota when hydrograph analysis needed such as pond design
- Also used by MnDOT for peak flow for most culverts where drainage area is smaller than what recommended for StreamStats



















#### NRCS Hydrology

- NRCS/SCS Rainfall/Runoff Hydrology Method
  - Drainage Area
  - Curve Number based on land use and soil properties - proportion of precipitation that will runoff drainage area
  - 24 hour design precipitation
  - Time of Concentration time for water to flow from furthest part of watershed to design point
  - Rainfall distribution intensity of precipitation over time (24 hours)
  - Unit hydrograph rate of flow vs time for the runoff from the watershed



















#### Minnesota NRCS Recommendation

 Recommendations for NRCS Area and Field Staff for NRCS projects for rural watersheds

http://www.nrcs.usda.gov/wps/PA\_NRCSConsumption/download?cid=stelprdb1270686&ext=pdf

- Use Precipitation Depths from Atlas 14
- MSE 3 MN
  - MSE 3 rainfall distribution
  - Synthetic unit hydrograph with peak rate factor of 400
- Use Time of Concentration developed from Engineering Field Handbook (EFH2) or Folmar & Miller formula
- Flowchart




















#### Minnesota NRCS Recommendation





















### MnDOT Application of NRCS Recommendation

- ▶ Tech Memo <u>15-10-B-02</u>
- Urban Areas
  - Stop using NRCS Type II Rainfall Distribution
  - Use Atlas 14 Rainfall Depth from PFDS server or NRCS County File
  - Use MSE 3 or Atlas 14 Derived Rainfall Distribution
  - Use SCS Typical Unit Hydrograph (peak factor 484)
  - Use Time of Concentration formulas from Drainage Manual/TR-55
  - Route flow (hydrograph analysis) where have storage



















### MnDOT Application of NRCS Recommendation

#### Rural Areas

- Stop using NRCS Type II Rainfall Distribution
- Use Atlas 14 Rainfall depth
- Use MSE 3 or Atlas 14 Derived Rainfall Distribution
- Use standard dimensionless unit hydrograph with peak factor of 484 unless conditions on following slide met.
- Route flow (hydrograph analysis) if significant storage, especially right upstream of crossing.



















### MnDOT Application of NRCS Recommendation

- Rural Areas cont'd
  - Minnesota NRCS recommended methodology
    - MSE 3 rainfall distribution
    - Unit Hydrograph with peak factor of 400
    - Time of Concentration methods per NRCS flowchart
  - MN NRCS MSE 3 MN and Time of Concentration methodology may used for some rural drainage areas when all of the following conditions met:
    - Drainage area is rural
    - Drainage area is not steep
    - Predicted flows are consistent with historical observations at the site.



















## Using Atlas 14/NRCS resources in HydroCAD

Rainfall Depth – use either method below:

- Import rainfall depths from Atlas 14 PFDS server
   helpsheet on web site
- NRCS County file included with HydroCAD 10 Build 15 or higher – slides to follow

Rainfall Distribution - use either method below:

- Import rainfall distribution from Atlas 14 PFDS server – helpsheet on web site
- NRCS MSE 3 rainfall distribution included with HydroCAD 10 Build 14 or higher – slides to follow




















# Selecting NRCS MSE-3 Rainfall Distribution in HydroCAD

Select
Calculation
Settings
Dialog and
select Rainfall
Tab

Select MSE 24-hr as Storm Type










# Selecting NRCS MSE-3 Rainfall Distribution in HydroCAD

Then selectStormCurve 3










# Select 24 hour rainfall depth from HydroCAD Lookup File

On Calculation Settings dialog/Rainfall Tab

- Go to Rainfall Event and click on Import Events From button
- Select Lookup
  Table





















# Select 24 hour rainfall depth from HydroCAD Lookup File

On Rainfall Event Lookup Table:

- 1. Select Event Lookup File Atlas-14-Rain.txt
- 2. Find State = MN
- 3. Scroll down and find county
- 4. Click on OK






















## Select 24 hour rainfall depth from HydroCAD Lookup File

Select MSE 3 as Storm Distribution and OK

Data is from
Minnesota NRCS
County file and is
the spatially
averaged value for
the county.





















### Using NRCS Recommendations in HydroCAD - MSE 3 Rainfall Distribution

Rainfall Distribution	Peak Flow
Atlas 14	162 cfs
NRCS – MSE3	167 cfs
SCS Type II	151 cfs

- Stearns County
- Drainage Area = 100 acres
- ▶ Tc = 64 minutes
- CN = 75
- ▶ 24 hour Rainfall = 5.68 in




















#### Minnesota NRCS - Unit Hydrograph






















# Selecting Peak Factor 400 Unit Hydrograph in HydroCAD

SCS is the default

Select peak factor 400 dimensionless unit hydrograph by going to

Settings > Calculation > Unit Hydro





















#### Impact of Unit Hydrograph

Rainfall Distribution	Peak Flow – SCS Unit hydrograph (Peak Factor 484)	Peak Flow – NRCS Peak Factor 400
Atlas 14	162 cfs	
NRCS – MSE3	167 cfs	145 cfs MSE3 MN
SCS Type II	151 cfs	

- Stearns County
- Tc = 64 minutes
- ► CN = 75
- ▶ 24 hour Rainfall = 5.66 in




















#### Review Options in Summary!





















## Using NRCS Methodology in HydroCAD – versions

- HydroCAD 10 build 15
  - Includes county data file that includes Atlas 14 data for Minnesota counties
- HydroCAD 10 build 14 or higher
  - Includes MSE 3 rainfall distribution
- HydroCAD 10 build prior to 14
  - Can import Atlas 14 rainfall distribution downloaded from PFDS server
  - Includes unit hydrograph with peak factor 400
- HydroCAD version 9
  - Can not import Atlas 14 rainfall distribution
  - Need to develop a custom rainfall distribution for MSE 3 based on data from NRCS



















# Impact of Rainfall Distribution/Unit Hydrograph

- For Peak Flow method most impact for areas with shorter Time of Concentration
- If route flow, especially if have significant amounts of storage, the unit hydrograph and rainfall distribution used have much less impact



















#### Recommendations

- Stop using NRCS Type II rainfall distribution
- Use Atlas 14 derived distribution or MSE-3 distribution
- ▶ For urban watersheds continue to dimensionless unit hydrograph with peak factor of 484 (default in HydroCAD)
- Document what is used



















#### Recommendations

- Allowable to use NRCS Recommended Method for rural areas – MSE 3 MN
  - MSE 3 Rainfall Distribution
  - Unit Hydrograph with peak factor 400
- Use engineering judgment and continue to use typical SCS unit hydrograph (PF 484) where higher design flow justified:
  - Rural vs Agricultural
  - Climate Change resilience
  - No Storage
  - History of Flooding
  - Critical locations
  - Steepness/flashiness

















